



Single Roxy Bed Assembly Guide

1. Layout panels as shown, so that matching letters are together; A to A, B to B etc.
2. Slot side panels brackets onto the Headboards Timber - Fix through Bracket (20mm Silver Screw) & Headboard (40mm Silver Bolt)
3. Align the End panel with Side panels and Fix through Bracket (20mm Silver Bolt) & End side.(40mm Silver Screw)
4. Place the reinforcement bar across centre of bed, again, matching A to A, B to B etc. and Fix (35mm Brass Bolts)
5. Carefully slide bed base into position on head end, fix with round head screws using allen key. (60mm Brass Bolts)

